

Powertek-Neaco | MRO Services | FAA Approved Repair Services Parts ListContact: +44 118 370 2004 info@powertekuk.com | Mob +44 (0)7398669279 | +1 631 824 4666 info@powertekus.com

FAA European Union Aviation Safety Agency validity of Part-145 approval: EASA.145.4703

Description	Manufacturer	ATA Aircraft	Part Number
GENERAL ELECTRICARBOX	GOODRICH	27 A320, A319, A321	790A0000-01
GENERAL ELECTRICARBOX	GOODRICH	27 A319, A320, A321	790A0000-02
GENERAL ELECTRICARBOX	GOODRICH	27 A319, A321, A320	790A0000-03
ACTUATOR	LIEBHERR	27 A319, A320, A321	830A0000-01
VALVE	NORD MICRO	21 A319, A320, A321	9024-15704-2
ACTUATOR	LIEBHERR	21 A319, A320, A321, A330, A340	9069A1002-01
ACTUATOR	LIEBHERR	21 A319, A320, A321, A330, A340	9069A1003-01
ACTUATOR	LIEBHERR	21 A319, A320, A321, A330, A340	9069A1003-02
ACTUATOR	LIEBHERR	21 A319, A320, A321, A330, A340	9069A1015-01
ACTUATOR	LIEBHERR	21 A319, A320, A321, A330, A340	9069B1002-01
SENSOR	LIEBHERR	21 A319, A320, A321	9104A0003-01
SENSOR	LIEBHERR	21 A319, A320, A321	9104A0003-03
SWITCH	LIEBHERR	21 A320, A319, A321	9106A0003-02
SENSOR	LIEBHERR	21 A320, A319, A321	9106A0005-01
VALVE	LIEBHERR	21 A319, A320, A321, A340	963A0000-02
VALVE	DUNLOP	75 A319, A320, B737, A318, A321, MD-90	AC69572
VALVE	LIEBHERR	21 A319, A320, A321	B17CA1041
VALVE	LIEBHERR	21 A319, A320, A321	B17CA1042
SWITCH	FR-HITEMP	28 A319, A320, A321, A340	FRH100013A
SWITCH	FR-HITEMP	28 A319, A320, A321, A340	FRH100028A
ACTUATOR	EATON	28 A319, A320, A321, A310	HTE200002
ACTUATOR	EATON	29 A319, A321, A320	HTE200002-1
CONTACT	EATON	28 A320, A340, A310, A300, A330, A319, A321	HTE69000-1
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-601
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-602
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-602-1
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-603
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-604
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-605
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-606
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-607
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-608
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-609
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-610
VALVE	INTERTECHNIQUE	28 A319, A321, A320	L83A13-611
VALVE	LIEBHERR	29 A300, A319, A320, A321	S4-3400920-02
VALVE	LIEBHERR	52 A319, A320, A321, A330, A340	S4-3402180
VALVE	NORD-MIRCO	21 A319, A321, A320	12432-1
VALVE	NORD MICRO	21 A319, A321, A320	12432-2
AIR CYCLE MACHINE	LIEBHERR	21 A319, A320, A321	1263A0000-01
VALVE	LIEBHERR	21 A319, A320, A321	1298A0000-01
VALVE	LIEBHERR	21 A319, A321, A320	1303A0000-01
VALVE	LIEBHERR	21 A319, A321, A320	1303A0000-02
VALVE	LIEBHERR	21 A319, A321, A320	1303A0000-03
VALVE	LIEBHERR	21 A320, A319, A321, A320	1303A0000-04
VALVE	LIEBHERR	21 A320, A319, A321	1312A0000-01
VALVE	LIEBHERR	21 A319, A320, A321, A340	1320A0000-01
VALVE	LIEBHERR	52 A319, A320, A321, A330, A340	1567A0000-01
PLENUM	LIEBHERR	21 A319, A320, A321	1816A0000-01
VALVE	LIEBHERR	32 A319, A320, A321	1905A0000-01
HEATER	LIEBHERR	21 A320, A321	1986A0000-01
MOTOR	HONEYWELL	49 MD80, A310, A321, A320, DC9	2000866-2
MOTOR	HONEYWELL	49 MD80, A310, A321, A320, DC9	2000866-3
MOTOR	HONEYWELL	49 DC9, MD80, A319, A320, A321, A310	2000866-4
PLENUM	LIEBHERR	21 A319, A320, A321	2056A0000-02
PLENUM	LIEBHERR	21 A319, A320, A321	2056B0000-01
AIR CYCLE MACHINE	HONEYWELL	21 A319, A320, A321	2206720-3
AIR CYCLE MACHINE	HONEYWELL	21 A319, A320, A321	2206720-4
AIR CYCLE MACHINE	HONEYWELL	21 A319, A320, A321	2206720-5
SENSOR	LIEBHERR	21 A319, A320, A321	2687A0000-01

Powertek Neaco MRO Capabilities

SENSOR	LIEBHERR	21 A319, A320, A321	2695A0000-01
SENSOR	LIEBHERR	21 A319, A320, A321	2696A0000-01
SENSOR	LIEBHERR	21 A319, A320, A321	2697A0000-01
SENSOR	LIEBHERR	21 A319, A320, A321	2698A0000-01
SENSOR	LIEBHERR	21 A319, A320, A321	2699A0000-01
MOTOR	HONEYWELL	49 A319, A320, A321	2704506-2
VALVE	PARKER	29 A319, A320, A321	2910045-101
VALVE	PARKER	29 A319, A320, A321	2910045-102
VALVE	PARKER	29 A319, A320, A321	2910045-103
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-1
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-12
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-14
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-15
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-2
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-22
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-23
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-24
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-25
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-26
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-27
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-3
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-4
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-40
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-41
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-42
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-43
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-44
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-45
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-60
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-61
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-62
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-63
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-64
STARTER	HONEYWELL	80 A319, A320, A321, A340	3505582-65
VALVE	HONEYWELL	30 A321, A340, A330, A320	38E93-4
VALVE	HONEYWELL	30 A321, A340, A330, A320, A319	38E93-5
VALVE	LIEBHERR	21 A319, A320, A321	3957A0000-02
VALVE	LIEBHERR	21 A319, A320, A321	3958A0000-01
VALVE	NORD MICRO	21 A310, A320, A319, A321	4063-18221
ACTUATOR	ELEKTRO METALL	21 A319, A320, A321	41-2-1100
ACTUATOR	ELEKTRO METALL	21 A319, A320, A321	41-2-1100-01
ACTUATOR	ELEKTRO METALL	21 A319, A321, A320	41-2-1100-02
ACTUATOR	NORD MICRO	21 A320, A319, A321, A320	6610-15945
ACTUATOR	NORD MICRO	21 A300, A320, A330, A340, A319, A321	6610-20560-01
VALVE	LIEBHERR	36 A319, A320, A321	6733A030000
SENSOR	LIEBHERR	21 A319, A320, A321	736A0000-01
SENSOR	LIEBHERR	21 A319, A320, A321	736A0000-02
PIPE	LIEBHERR	21 A319, A320, A321	744A1100-01
VALVE	LIEBHERR	21 A319, A320, A321	746A0000-04
VALVE	LIEBHERR	21 A319, A320, A321	746A0000-05
VALVE	LIEBHERR	21 A319, A320, A321	746A0000-06
VALVE	LIEBHERR	21 A319, A320, A321	748A0000-01
VALVE	LIEBHERR	21 A319, A320, A321	748A0000-04
VALVE	LIEBHERR	21 A319, A320, A321	748A0000-05
VALVE	LIEBHERR	21 A319, A320, A321	748A0000-07
VALVE	LIEBHERR	21 A319, A320, A321	748A0000-08
VALVE	LIEBHERR	21 A319, A320, A321	750A0000-02
VALVE	LIEBHERR	21 A319, A320, A321	751A0000-04
VALVE	LIEBHERR	21 A319, A320, A321	VALVE
VALVE	LIEBHERR	21 A319, A320, A321	751A0000-06
VALVE	LIEBHERR	21 A319, A320, A321	751A0000-07
AIR CYCLE MACHINE	LIEBHERR	21 A319, A321, A320	757C0000-01
AIR CYCLE MACHINE	LIEBHERR	21 A319, A321, A320	757C0000-02
VALVE	LIEBHERR	21 A319, A321, A320	758A0000-02
ACTUATOR	LIEBHERR	21 A319, A320, A321	761A0000-03
ACTUATOR	LIEBHERR	21 A319, A320, A321	761A0000-04
ACTUATOR	LIEBHERR	21 A319, A320, A321	761B0000-01

Powertek Neaco MRO Capabilities

ACTUATOR	LIEBHERR	21 A319, A320, A321	762A0000-03
ACTUATOR	LIEBHERR	21 A319, A320, A321	762A0000-04
SENSOR	LIEBHERR	80 A319, A320, A321	763A0000-01
SWITCH	LIEBHERR	21 A319, A320, A321	763A0000-02
SWITCH	LIEBHERR	21 A319, A320, A321	763A0000-03
SENSOR	LIEBHERR	21 A320, A319, A321	764A0000-01
SWITCH	LIEBHERR	21 A320, A319, A321	764A0000-03
SWITCH	LIEBHERR	21 A320, A319, A321	764B0000-01
SENSOR	LIEBHERR	21 A320, A319, A321	766A0000-01
SENSOR	LIEBHERR	21 A320, A319, A321	B767A0000-03
SENSOR	LIEBHERR	21 A320, A319, A321	B767A0000-04
SENSOR	LIEBHERR	21 A320, A319, A321	B767B0000-01
SENSOR	LIEBHERR	21 A320, A319, A321	B767B0000-02
SENSOR	LIEBHERR	21 A320, A319, A321	B767B0000-04
SENSOR	LIEBHERR	21 A320, A319, A321	B767C0000-01
SENSOR	LIEBHERR	21 A320, A319, A321	768A0000-02
SENSOR	LIEBHERR	21 A319, A320, A321	768A0000-03
SENSOR	LIEBHERR	21 A319, A320, A321, A340	773A0000-01